

SECTION LAN

LAN SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CONTENTS

CAN FUNDAMENTAL		PRECAUTIONS	20
PRECAUTION	4	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	20
PRECAUTIONS	4	Precaution for Battery Service	20
Precautions for Trouble Diagnosis	4	Precautions for Trouble Diagnosis	20
Precautions for Harness Repair	4	Precautions for Harness Repair	20
FUNCTION DIAGNOSIS	5	BASIC INSPECTION	22
CAN COMMUNICATION SYSTEM	5	DIAGNOSIS AND REPAIR WORKFLOW	22
System Description	5	Interview Sheet	22
System Diagram	5	FUNCTION DIAGNOSIS	23
CAN Communication Control Circuit	6	CAN COMMUNICATION SYSTEM	23
DIAG ON CAN	7	CAN System Specification Chart	23
Description	7	CAN Communication Signal Chart	23
System Diagram	7	COMPONENT DIAGNOSIS	26
TROUBLE DIAGNOSIS	8	CAN COMMUNICATION SYSTEM	26
Condition of Error Detection	8	Component Parts Location	26
Symptom When Error Occurs in CAN Communication System	8	Wiring Diagram - CAN SYSTEM -	27
CAN Diagnosis with CONSULT-III	11	MALFUNCTION AREA CHART	32
Self-Diagnosis	11	Main Line	32
CAN Diagnostic Support Monitor	11	Branch Line	32
How to Use CAN Communication Signal Chart	13	Short Circuit	32
BASIC INSPECTION	14	MAIN LINE BETWEEN 4WD AND BCM CIRCUIT	33
DIAGNOSIS AND REPAIR WORKFLOW	14	Diagnosis Procedure	33
Trouble Diagnosis Flow Chart	14	MAIN LINE BETWEEN BCM AND M&A CIRCUIT	34
Trouble Diagnosis Procedure	14	Diagnosis Procedure	34
CAN		MAIN LINE BETWEEN M&A AND STRG CIRCUIT	35
HOW TO USE THIS MANUAL	19	Diagnosis Procedure	35
HOW TO USE THIS SECTION	19		
Caution	19		
Abbreviation List	19		
PRECAUTION	20		

MAIN LINE BETWEEN STRG AND DLC CIRCUIT	36	MAIN LINE BETWEEN BCM AND M&A CIRCUIT	56
Diagnosis Procedure	36	Diagnosis Procedure	56
MAIN LINE BETWEEN DLC AND TCM CIRCUIT	37	MAIN LINE BETWEEN M&A AND STRG CIRCUIT	57
Diagnosis Procedure	37	Diagnosis Procedure	57
MAIN LINE BETWEEN TCM AND ABS CIRCUIT	38	MAIN LINE BETWEEN STRG AND DLC CIRCUIT	58
Diagnosis Procedure	38	Diagnosis Procedure	58
ECM BRANCH LINE CIRCUIT	39	MAIN LINE BETWEEN DLC AND TCM CIRCUIT	59
Diagnosis Procedure	39	Diagnosis Procedure	59
4WD BRANCH LINE CIRCUIT	40	MAIN LINE BETWEEN TCM AND ABS CIRCUIT	60
Diagnosis Procedure	40	Diagnosis Procedure	60
A-BAG BRANCH LINE CIRCUIT	41	ECM BRANCH LINE CIRCUIT	61
Diagnosis Procedure	41	Diagnosis Procedure	61
BCM BRANCH LINE CIRCUIT	42	4WD BRANCH LINE CIRCUIT	62
Diagnosis Procedure	42	Diagnosis Procedure	62
E-SUS BRANCH LINE CIRCUIT	43	A-BAG BRANCH LINE CIRCUIT	63
Diagnosis Procedure	43	Diagnosis Procedure	63
AV BRANCH LINE CIRCUIT	44	BCM BRANCH LINE CIRCUIT	64
Diagnosis Procedure	44	Diagnosis Procedure	64
HVAC BRANCH LINE CIRCUIT	45	E-SUS BRANCH LINE CIRCUIT	65
Diagnosis Procedure	45	Diagnosis Procedure	65
M&A BRANCH LINE CIRCUIT	46	AV BRANCH LINE CIRCUIT	66
Diagnosis Procedure	46	Diagnosis Procedure	66
STRG BRANCH LINE CIRCUIT	47	HVAC BRANCH LINE CIRCUIT	67
Diagnosis Procedure	47	Diagnosis Procedure	67
DLC BRANCH LINE CIRCUIT	48	M&A BRANCH LINE CIRCUIT	68
Diagnosis Procedure	48	Diagnosis Procedure	68
TPMS BRANCH LINE CIRCUIT	49	STRG BRANCH LINE CIRCUIT	69
Diagnosis Procedure	49	Diagnosis Procedure	69
TCM BRANCH LINE CIRCUIT	50	DLC BRANCH LINE CIRCUIT	70
Diagnosis Procedure	50	Diagnosis Procedure	70
ABS BRANCH LINE CIRCUIT	51	TPMS BRANCH LINE CIRCUIT	71
Diagnosis Procedure	51	Diagnosis Procedure	71
IPDM-E BRANCH LINE CIRCUIT	52	TCM BRANCH LINE CIRCUIT	72
Diagnosis Procedure	52	Diagnosis Procedure	72
CAN COMMUNICATION CIRCUIT	53	ABS BRANCH LINE CIRCUIT	73
Diagnosis Procedure	53	Diagnosis Procedure	73
CAN SYSTEM (TYPE 1)			
COMPONENT DIAGNOSIS	55	IPDM-E BRANCH LINE CIRCUIT	74
MAIN LINE BETWEEN 4WD AND BCM CIRCUIT	55	Diagnosis Procedure	74
Diagnosis Procedure	55	CAN COMMUNICATION CIRCUIT	75

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

PRECAUTION

PRECAUTIONS

Precautions for Trouble Diagnosis

INFOID:000000003931345

CAUTION:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precautions for Harness Repair

INFOID:000000003931346

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

FUNCTION DIAGNOSIS

CAN COMMUNICATION SYSTEM


System Description

INFOID:000000003931347

- CAN communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with two communication lines (CAN-H and CAN-L).
- Control units on the CAN network transmit signals using the CAN communication control circuit. They receive only necessary signals from other control units to operate various functions.
- CAN communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

System Diagram

INFOID:000000003931348



Each control unit passes an electric current to the termination circuits when transmitting CAN communication signal. The termination circuits produce an electrical potential difference between CAN-H and CAN-L. CAN communication system transmits and receives CAN communication signals by the potential difference.

LAN

Component	Description
Main line	CAN communication line between splices
Branch line	CAN communication line between splice and a control unit
Splice	A point connecting a branch line with a main line
Termination circuit	Refer to LAN-6. "CAN Communication Control Circuit" .

N
O
P


CAN COMMUNICATION SYSTEM

< FUNCTION DIAGNOSIS >

[CAN FUNDAMENTAL]

CAN Communication Control Circuit

INFOID:000000003931349



Component	System description
CAN controller	It controls CAN communication signal transmission and reception, error detection, etc.
Transceiver IC	It converts digital signal into CAN communication signal, and CAN communication signal into digital signal.
Noise filter	It eliminates noise of CAN communication signal.
Termination circuit* (Resistance of approx. 120 Ω)	It produces potential difference.

*: These are the only control units wired with both ends of CAN communication system.

DIAG ON CAN


Description

INFOID:000000003931350

“Diag on CAN” is a diagnosis using CAN communication instead of previous DDL1 and DDL2 communication lines, between control units and diagnosis unit.

System Diagram

INFOID:000000003931351



Name	Harness	Description
DDL1	Tx Rx	It is used for trouble diagnosis. (CAN-H and CAN-L are used for controlling)
DDL2	K-LINE	It is used for trouble diagnosis. (CAN-H and CAN-L are used for controlling)
Diag on CAN	CAN-H CAN-L	It is used for trouble diagnosis and control.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

TROUBLE DIAGNOSIS

Condition of Error Detection

INFOID:000000003931352

“U1000” or “U1001” is indicated on SELF-DIAG RESULTS on CONSULT-III if CAN communication signal is not transmitted or received between units for 2 seconds or more.

CAN COMMUNICATION SYSTEM ERROR

- CAN communication line open (CAN-H, CAN-L, or both)
- CAN communication line short (ground, between CAN communication lines, other harnesses)
- Error of CAN communication control circuit of the unit connected to CAN communication line

WHEN “U1000” OR “U1001” IS INDICATED EVEN THOUGH CAN COMMUNICATION SYSTEM IS NORMAL

- Removal/installation of parts: Error may be detected when removing and installing CAN communication unit and related parts while turning the ignition switch ON. (A DTC except for CAN communication may be detected.)
- Fuse blown out (removed): CAN communication of the unit may cease.
- Voltage drop: Error may be detected if voltage drops due to discharged battery when turning the ignition switch ON (Depending on the control unit which carries out CAN communication).
- Error may be detected if the power supply circuit of the control unit, which carries out CAN communication, malfunctions (Depending on the control unit which carries out CAN communication).
- Error may be detected if reprogramming is not completed normally.

NOTE:

CAN communication system is normal if “U1000” or “U1001” is indicated on SELF-DIAG RESULTS of CONSULT-III under the above conditions. Erase the memory of the self-diagnosis of each unit.

Symptom When Error Occurs in CAN Communication System

INFOID:000000003931353


In CAN communication system, multiple units mutually transmit and receive signals. Each unit cannot transmit and receive signals if any error occurs on CAN communication line. Under this condition, multiple control units related to the root cause malfunction or go into fail-safe mode.

ERROR EXAMPLE

NOTE:

- Each vehicle differs in symptom of each unit under fail-safe mode and CAN communication line wiring.
- Refer to [LAN-19. "Abbreviation List"](#) for the unit abbreviation.

Example: TCM branch line open circuit



Unit name	Symptom
ECM	Engine torque limiting is affected, and shift harshness increases.
BCM	Reverse warning chime does not sound.


TROUBLE DIAGNOSIS

< FUNCTION DIAGNOSIS >

[CAN FUNDAMENTAL]

Unit name	Symptom
EPS control unit	Normal operation.
Combination meter	<ul style="list-style-type: none"> Shift position indicator and OD OFF indicator turn OFF. Warning lamps turn ON.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	Normal operation.

Example: Data link connector branch line open circuit



Unit name	Symptom
ECM	Normal operation.
BCM	
EPS control unit	
Combination meter	
ABS actuator and electric unit (control unit)	
TCM	
IPDM E/R	

NOTE:

- When data link connector branch line is open, transmission and reception of CAN communication signals are not affected. Therefore, no symptoms occur. However, be sure to repair malfunctioning circuit.
- The model (all units on CAN communication system are Diag on CAN) cannot perform CAN diagnosis with CONSULT-III if the following error occurs. The error is judged by the symptom.

Error	Difference of symptom
Data link connector branch line open circuit	Normal operation.
CAN-H, CAN-L harness short-circuit	Most of the units which are connected to the CAN communication system enter fail-safe mode or are deactivated.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


LAN

TROUBLE DIAGNOSIS

< FUNCTION DIAGNOSIS >


[CAN FUNDAMENTAL]

Example: Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Open Circuit



Unit name	Symptom
ECM	Engine torque limiting is affected, and shift harshness increases.
BCM	<ul style="list-style-type: none"> Reverse warning chime does not sound. The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position.
EPS control unit	The steering effort increases.
Combination meter	<ul style="list-style-type: none"> The shift position indicator and OD OFF indicator turn OFF. The speedometer is inoperative. The odo/trip meter stops.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	When the ignition switch is ON, <ul style="list-style-type: none"> The headlamps (Lo) turn ON. The cooling fan continues to rotate.

Example: CAN-H, CAN-L Harness Short Circuit



TROUBLE DIAGNOSIS

< FUNCTION DIAGNOSIS >

[CAN FUNDAMENTAL]

Unit name	Symptom
ECM	<ul style="list-style-type: none"> • Engine torque limiting is affected, and shift harshness increases. • Engine speed drops.
BCM	<ul style="list-style-type: none"> • Reverse warning chime does not sound. • The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position. • The room lamp does not turn ON. • The engine does not start (if an error or malfunction occurs while turning the ignition switch OFF.) • The steering lock does not release (if an error or malfunction occurs while turning the ignition switch OFF.)
EPS control unit	The steering effort increases.
Combination meter	<ul style="list-style-type: none"> • The tachometer and the speedometer do not move. • Warning lamps turn ON. • Indicator lamps do not turn ON.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	When the ignition switch is ON, <ul style="list-style-type: none"> • The headlamps (Lo) turn ON. • The cooling fan continues to rotate.

CAN Diagnosis with CONSULT-III

INFOID:000000003931354

CAN diagnosis on CONSULT-III extracts the root cause by receiving the following information.

- Response to the system call
- Control unit diagnosis information
- Self-diagnosis
- CAN diagnostic support monitor

Self-Diagnosis

INFOID:000000004155357

DTC	Self-diagnosis item (CONSULT-III indication)	DTC detection condition	Inspection/Action
U0101	LOST COMM (TCM)	When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) from TCM for 2 seconds or more.	Start the inspection. Refer to the applicable section of the indicated control unit.
U0164	LOST COMM (HVAC)	When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) from HVAC for 2 seconds or more.	
U1000	CAN COMM CIRCUIT	When a control unit (except for ECM) is not transmitting or receiving CAN communication signal for 2 seconds or more.	
U1001	CAN COMM CIRCUIT	When ECM is not transmitting or receiving CAN communication signal other than OBD (emission-related diagnosis) for 2 seconds or more.	
U1002	SYSTEM COMM	When a control unit is not transmitting or receiving CAN communication signal for 2 seconds or less.	
U1010	CONTROL UNIT(CAN)	When an error is detected during the initial diagnosis for CAN controller of each control unit.	Replace the control unit indicating "U1010" or "P0607".
P0607	ECM		

CAN Diagnostic Support Monitor

INFOID:000000003931356

MONITOR ITEM (CONSULT-III)

TROUBLE DIAGNOSIS

< FUNCTION DIAGNOSIS >

[CAN FUNDAMENTAL]

Example: CAN DIAG SUPPORT MNTR indication

Without PAST			With PAST		
ECM			ECM		
	PRSNT	PAST		PRSNT	PAST
INITIAL DIAG	OK		TRANSMIT DIAG	OK	OK
TRANSMIT DIAG	OK		VDC/TCS/ABS	-	-
TCM	OK		METER/M&A	OK	OK
VDC/TCS/ABS	UNKWN		BCM/SEC	OK	OK
METER/M&A	OK		ICC	-	-
ICC	UNKWN		HVAC	-	-
BCM/SEC	OK		TCM	OK	OK
IPDM E/R	OK		EPS	-	-
			IPDM E/R	OK	OK
			e4WD	-	-
			AWD/4WD	OK	OK

JSMIA00156B

Without PAST

Item	PRSNT	Description
Initial diagnosis	OK	Normal at present
	NG	Control unit error (Except for some control units)
Transmission diagnosis	OK	Normal at present
	UNKWN	Unable to transmit signals for 2 seconds or more. Diagnosis not performed
Control unit name (Reception diagnosis)	OK	Normal at present
	UNKWN	Unable to receive signals for 2 seconds or more. Diagnosis not performed
	UNKWN	No control unit for receiving signals. (No applicable optional parts)

With PAST

Item	PRSNT	PAST	Description
Transmission diagnosis	OK	OK	Normal at present and in the past
		1 – 39	Normal at present, but unable to transmit signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.)
	UNKWN	0	Unable to transmit signals for 2 seconds or more at present.
Control unit name (Reception diagnosis)	OK	OK	Normal at present and in the past
		1 – 39	Normal at present, but unable to receive signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.)
	UNKWN	0	Unable to receive signals for 2 seconds or more at present.
	-	-	Diagnosis not performed. No control unit for receiving signals. (No applicable optional parts)

MONITOR ITEM (ON-BOARD DIAGNOSIS)

NOTE:

For some models, CAN communication diagnosis result is received from the vehicle monitor.

TROUBLE DIAGNOSIS

< FUNCTION DIAGNOSIS >

[CAN FUNDAMENTAL]

Example: Vehicle Display

Item	Result indicated	Error counter	Description
CAN_COMM (Initial diagnosis)	OK	0	Normal at present
	NG	1 – 50	Control unit error (The number indicates how many times diagnosis has been run.)
CAN_CIRC_1 (Transmission diagnosis)	OK	0	Normal at present
	UNKWN	1 – 50	Unable to transmit for 2 seconds or more at present. (The number indicates how many times diagnosis has been run.)
CAN_CIRC_2 – 9 (Reception diagnosis of each unit)	OK	0	Normal at present
	UNKWN	1 – 50	Unable to transmit for 2 seconds or more at present. (The number indicates how many times diagnosis has been run.)
			Diagnosis not performed.
			No control unit for receiving signals. (No applicable optional parts)

How to Use CAN Communication Signal Chart

INFOID:000000003931357

The CAN communication signal chart lists the signals needed for trouble diagnosis. It is useful for detecting the root cause by finding a signal related to the symptom, and by checking transmission and reception unit.

Example: Tachometer does not move even though the engine rotates.

T: Transmit R: Receive

Signal name/Connecting unit	ECM	BCM	M&A	STRG	ABS	IPDM-E
A/C compressor feedback signal	T		R			
A/C compressor request signal	T					R
Accelerator pedal position signal	T				R	
Cooling fan motor operation signal	T					R
Engine coolant temperature signal	T		R			
Engine speed signal	T		R		R	
Fuel consumption monitor signal	T		R			
Malfunction indicator lamp signal	T		R			
A/C switch signal	R	T				
Ignition switch signal		T				R
Sleep/wake up signal		T	R			R

No communication between ECM and M&A.

It indicates that an error occurs between ECM and M&A (Shaded area).

SK1188715E

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


LAN

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Trouble Diagnosis Flow Chart

INFOID:000000003931358



Trouble Diagnosis Procedure

INFOID:000000003931359

INTERVIEW WITH CUSTOMER

Interview with the customer is important to detect the root cause of CAN communication system errors and to understand vehicle condition and symptoms for proper trouble diagnosis.

Points in interview

- What: Parts name, system name
- When: Date, Frequency
- Where: Road condition, Place
- In what condition: Driving condition/environment
- Result: Symptom

NOTE:


- Check normal units as well as error symptoms.
- Example: Circuit between ECM and the combination meter is judged normal if the customer indicates tachometer functions normally.
- When a CAN communication system error is present, multiple control units may malfunction or go into fail-safe mode.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

- Indication of the combination meter is important to detect the root cause because it is the most obvious to the customer, and it performs CAN communication with many units.



INSPECTION OF VEHICLE CONDITION

Check whether the symptom is reproduced or not.

NOTE:

Do not turn the ignition switch OFF or disconnect the battery cable while reproducing the error. The error may temporarily correct itself, making it difficult to determine the root cause.

CHECK OF CAN SYSTEM TYPE (HOW TO USE CAN SYSTEM TYPE SPECIFICATION CHART)

Determine CAN system type based on vehicle equipment.

NOTE:

- This chart is used if CONSULT-III does not automatically recognize CAN system type.
- There are two styles for CAN system type specification charts. Depending on the number of available system types, either style A or style B may be used.

CAN System Type Specification Chart (Style A)

NOTE:

A
B
C
D
E
F
G
H
I
J
K
L

LAN

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:
Vehicle is equipped as follows: Wagon, AWD, VQ35DE, CVT, VDC, and Intelligent Key system. (○ shows an example of CAN system type.)


CAN System Specification Chart
Determine CAN system type from the following specification chart.

Body type	Wagon					
Axle	2WD			AWD		
Engine	QR25DE		VQ35DE			
Transmission	A/T		CVT			
Brake control	ABS			VDC		
Intelligent Key system		X		X		X
CAN system type	1	2	3	4	5	6
CAN communication signal chart	XX-XX. "TYPE 1/TYPE 2"		XX-XX. "TYPE 3/TYPE 4"		XX-XX. "TYPE 5/TYPE 6"	

X : Applicable


VEHICLE EQUIPMENT IDENTIFICATION INFORMATION
NOTE:
Check CAN system type from the vehicle shape and equipment.

With VDC



VDC OFF switch

With Intelligent Key system



Ignition knob

[For the above case, CAN system type is "6".]

JSM1A0017GB

CAN System Type Specification Chart (Style B)

NOTE:

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:
Vehicle is equipped as follows: Sedan, 2WD, MR20DE, CVT, ABS, Active AFS, Intelligent Key system, Navigation system and Automatic drive positioner. (○ shows an example of CAN system type.)

CAN System Specification Chart
Refer to the specification as shown in the chart.

Body type	Sedan		
Axle	2WD		AWD
Engine	HR15DE	MR20DE	HR15DE
Transmission	A/T	CVT	A/T
Brake control	ABS		
Specification chart	XX.XX...SPECIFICATION CHART A	YY.YY...SPECIFICATION CHART B	ZZ.ZZ...SPECIFICATION CHART C

x: Applicable

Check the vehicle equipment with the vehicle identification number plate.
Check the vehicle equipment.
Select the applicable vehicle equipment. Refer to the specification chart.

SPECIFICATION CHART B
Determine CAN system type from the following specification chart.

Body type	Sedan																			
Axle	2WD																			
Engine	MR20DE																			
Transmission	CVT																			
Brake control	ABS																			
Active AFS		x				x				x					x	x			x	x
Intelligent Key system			x				x				x				x	x			x	x
Navigation system				x				x							x	x			x	x
Automatic drive positioner																				x
CAN system type	9	10	11	12	13	14	15	16	17	18	19	20								
CAN communication signal chart	XX.XX...TYPE W/VOL.1 (TYPE W/VOL.1)TYPE W/VOL.2 (TYPE W/VOL.2)TYPE W/VOL.3 (TYPE W/VOL.3)TYPE W/VOL.4 (TYPE W/VOL.4)TYPE W/VOL.5 (TYPE W/VOL.5)TYPE W/VOL.6 (TYPE W/VOL.6)TYPE W/VOL.7 (TYPE W/VOL.7)TYPE W/VOL.8 (TYPE W/VOL.8)TYPE W/VOL.9 (TYPE W/VOL.9)TYPE W/VOL.10 (TYPE W/VOL.10)TYPE W/VOL.11 (TYPE W/VOL.11)TYPE W/VOL.12 (TYPE W/VOL.12)TYPE W/VOL.13 (TYPE W/VOL.13)TYPE W/VOL.14 (TYPE W/VOL.14)TYPE W/VOL.15 (TYPE W/VOL.15)TYPE W/VOL.16 (TYPE W/VOL.16)TYPE W/VOL.17 (TYPE W/VOL.17)TYPE W/VOL.18 (TYPE W/VOL.18)TYPE W/VOL.19 (TYPE W/VOL.19)TYPE W/VOL.20 (TYPE W/VOL.20)TYPE W/VOL.21 (TYPE W/VOL.21)TYPE W/VOL.22 (TYPE W/VOL.22)TYPE W/VOL.23 (TYPE W/VOL.23)TYPE W/VOL.24 (TYPE W/VOL.24)TYPE W/VOL.25 (TYPE W/VOL.25)TYPE W/VOL.26 (TYPE W/VOL.26)TYPE W/VOL.27 (TYPE W/VOL.27)TYPE W/VOL.28 (TYPE W/VOL.28)TYPE W/VOL.29 (TYPE W/VOL.29)TYPE W/VOL.30 (TYPE W/VOL.30)TYPE W/VOL.31 (TYPE W/VOL.31)TYPE W/VOL.32 (TYPE W/VOL.32)TYPE W/VOL.33 (TYPE W/VOL.33)TYPE W/VOL.34 (TYPE W/VOL.34)TYPE W/VOL.35 (TYPE W/VOL.35)TYPE W/VOL.36 (TYPE W/VOL.36)TYPE W/VOL.37 (TYPE W/VOL.37)TYPE W/VOL.38 (TYPE W/VOL.38)TYPE W/VOL.39 (TYPE W/VOL.39)TYPE W/VOL.40 (TYPE W/VOL.40)TYPE W/VOL.41 (TYPE W/VOL.41)TYPE W/VOL.42 (TYPE W/VOL.42)TYPE W/VOL.43 (TYPE W/VOL.43)TYPE W/VOL.44 (TYPE W/VOL.44)TYPE W/VOL.45 (TYPE W/VOL.45)TYPE W/VOL.46 (TYPE W/VOL.46)TYPE W/VOL.47 (TYPE W/VOL.47)TYPE W/VOL.48 (TYPE W/VOL.48)TYPE W/VOL.49 (TYPE W/VOL.49)TYPE W/VOL.50 (TYPE W/VOL.50)TYPE W/VOL.51 (TYPE W/VOL.51)TYPE W/VOL.52 (TYPE W/VOL.52)TYPE W/VOL.53 (TYPE W/VOL.53)TYPE W/VOL.54 (TYPE W/VOL.54)TYPE W/VOL.55 (TYPE W/VOL.55)TYPE W/VOL.56 (TYPE W/VOL.56)TYPE W/VOL.57 (TYPE W/VOL.57)TYPE W/VOL.58 (TYPE W/VOL.58)TYPE W/VOL.59 (TYPE W/VOL.59)TYPE W/VOL.60 (TYPE W/VOL.60)TYPE W/VOL.61 (TYPE W/VOL.61)TYPE W/VOL.62 (TYPE W/VOL.62)TYPE W/VOL.63 (TYPE W/VOL.63)TYPE W/VOL.64 (TYPE W/VOL.64)TYPE W/VOL.65 (TYPE W/VOL.65)TYPE W/VOL.66 (TYPE W/VOL.66)TYPE W/VOL.67 (TYPE W/VOL.67)TYPE W/VOL.68 (TYPE W/VOL.68)TYPE W/VOL.69 (TYPE W/VOL.69)TYPE W/VOL.70 (TYPE W/VOL.70)TYPE W/VOL.71 (TYPE W/VOL.71)TYPE W/VOL.72 (TYPE W/VOL.72)TYPE W/VOL.73 (TYPE W/VOL.73)TYPE W/VOL.74 (TYPE W/VOL.74)TYPE W/VOL.75 (TYPE W/VOL.75)TYPE W/VOL.76 (TYPE W/VOL.76)TYPE W/VOL.77 (TYPE W/VOL.77)TYPE W/VOL.78 (TYPE W/VOL.78)TYPE W/VOL.79 (TYPE W/VOL.79)TYPE W/VOL.80 (TYPE W/VOL.80)TYPE W/VOL.81 (TYPE W/VOL.81)TYPE W/VOL.82 (TYPE W/VOL.82)TYPE W/VOL.83 (TYPE W/VOL.83)TYPE W/VOL.84 (TYPE W/VOL.84)TYPE W/VOL.85 (TYPE W/VOL.85)TYPE W/VOL.86 (TYPE W/VOL.86)TYPE W/VOL.87 (TYPE W/VOL.87)TYPE W/VOL.88 (TYPE W/VOL.88)TYPE W/VOL.89 (TYPE W/VOL.89)TYPE W/VOL.90 (TYPE W/VOL.90)TYPE W/VOL.91 (TYPE W/VOL.91)TYPE W/VOL.92 (TYPE W/VOL.92)TYPE W/VOL.93 (TYPE W/VOL.93)TYPE W/VOL.94 (TYPE W/VOL.94)TYPE W/VOL.95 (TYPE W/VOL.95)TYPE W/VOL.96 (TYPE W/VOL.96)TYPE W/VOL.97 (TYPE W/VOL.97)TYPE W/VOL.98 (TYPE W/VOL.98)TYPE W/VOL.99 (TYPE W/VOL.99)TYPE W/VOL.100 (TYPE W/VOL.100)																			

x: Applicable

Check the vehicle equipment.
The number indicates the CAN system type of the vehicle.

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION
NOTE:
Check CAN system type from the vehicle shape and equipment.

With active AFS 	With Intelligent Key system
With navigation system 	With automatic drive positioner

In the above example,
• Checking Xenon bulb and bending lamp lead to judge whether or not Active AFS is equipped.
• Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.
• Checking display and multifunction switch lead to judge whether or not Navigation system is equipped.
• Checking seat memory switch leads to judge whether or not Automatic drive positioner is equipped.

[For the above case, CAN system type is "20".]

CREATE INTERVIEW SHEET

Fill out the symptom described by the customer, vehicle condition, and CAN system type on the interview sheet.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

Interview Sheet (Example)

CAN Communication System Diagnosis Interview Sheet	
Date received:	3, Feb. 2006
Type: DBA-KG11	VIN No.: KG11-005040
Model: BDRARGZ397EDA-E-J-	
First registration: 10, Jan. 2001	Mileage: 62,140
CAN system type: Type 19	
Symptom (Results from interview with customer)	
<ul style="list-style-type: none">•Headlamps suddenly turn ON while driving the vehicle.•The engine does not restart after stopping the vehicle and turning the ignition switch OFF.•The cooling fan continues rotating while turning the ignition switch ON.	
Condition at inspection	
Error Symptom: Present / Past	
The engine does not start. While turning the ignition switch ON, <ul style="list-style-type: none">•The headlamps (Lo) turn ON, and the cooling fan continues rotating.•The interior lamp does not turn ON.	

JSMIA0019GB

DETECT THE ROOT CAUSE

CAN diagnosis function of CONSULT-III detects the root cause.

HOW TO USE THIS SECTION

< HOW TO USE THIS MANUAL >

[CAN]

HOW TO USE THIS MANUAL

HOW TO USE THIS SECTION

Caution

INFOID:000000003931360

- This section describes information peculiar to a vehicle and inspection procedures.
- For trouble diagnosis procedure, refer to [LAN-14, "Trouble Diagnosis Procedure"](#).

Abbreviation List

INFOID:000000003931361

Unit name abbreviations in CONSULT-III CAN diagnosis and in this section are as per the following list.

Abbreviation	Unit name
4WD	AWD control unit
A-BAG	Air bag diagnosis sensor unit
ABS	ABS actuator and electric unit (control unit)
AV	AV control unit
BCM	BCM
DLC	Data link connector
ECM	ECM
E-SUS	E-SUS control unit
HVAC	A/C auto amp.
IPDM-E	IPDM E/R
M&A	Combination meter
STRG	Steering angle sensor
TCM	TCM
TPMS	Low tire pressure warning control unit

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004121810

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Battery Service

INFOID:000000004121811

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Precautions for Trouble Diagnosis

INFOID:000000003931363

CAUTION:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precautions for Harness Repair

INFOID:000000003931364

- Solder the repaired area and wrap tape around the soldered area.

NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



SK1B8766E

PRECAUTIONS


[CAN]

< PRECAUTION >

- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Interview Sheet

INFOID:000000003931365

CAN Communication System Diagnosis Interview Sheet

Date received:

Type:

VIN No.:

Model:

First registration:

Mileage:

CAN system type:

Symptom (Results from interview with customer)

Condition at inspection

Error symptom : Present / Past

SK18898E

CAN COMMUNICATION SYSTEM

< FUNCTION DIAGNOSIS >

[CAN]

FUNCTION DIAGNOSIS

CAN COMMUNICATION SYSTEM

CAN System Specification Chart

INFOID:000000003931366

Determine CAN system type from the following specification chart.

NOTE:

Refer to [LAN-14. "Trouble Diagnosis Procedure"](#) for how to use CAN system specification chart.

Body type	Coupe
Axle	AWD
Engine	VR38DETT
Transmission	Dual clutch transmission
Brake control	VDC
CAN system type	1

CAN Communication Signal Chart

INFOID:000000003931367

Refer to [LAN-13. "How to Use CAN Communication Signal Chart"](#) for how to use CAN communication signal chart.

NOTE:

Refer to [LAN-19. "Abbreviation List"](#) for the abbreviations of the connecting units.

T: Transmit R: Receive

Signal name/Connecting unit	ECM	4WD	BCM	E-SUS	AV	HVAC	M&A	STRG	TPMS	TCM	ABS	IPDM-E
A/C compressor feedback signal	T					R						
A/C compressor request signal	T											R
Accelerator pedal position signal	T	R								R	R	
ASCD status signal	T						R					
Cooling fan speed request signal	T											R
Engine and transmission integrated control signal	T									R		
	R									T		
Engine coolant temperature signal	T						R					
Engine estimated torque signal	T									R		
Engine speed signal	T	R		R			R			R	R	
Engine status signal	T		R									
Fuel consumption monitor signal	T						R					
Malfunctioning indicator lamp signal	T						R					
AWD clutch high temperature warning display signal		T					R					
AWD signal		T									R	
AWD system warning display signal		T					R					
AWD warning lamp signal		T					R					
Front/rear tire size discrepancy warning display signal		T					R					
Buzzer output signal			T				R					
Buzzer request signal			T				R					
			R						T			
Daytime running light request signal			T									R

CAN COMMUNICATION SYSTEM

< FUNCTION DIAGNOSIS >

[CAN]

Signal name/Connecting unit	ECM	4WD	BCM	E-SUS	AV	HVAC	M&A	STRG	TPMS	TCM	ABS	IPDME
Door switch signal			T				R					R
Front wiper request signal			T									R
High beam request signal			T									R
Horn reminder signal			T									R
Ignition switch ON signal			T									R
			R									T
Key warning lamp signal			T				R					
Low beam request signal			T									R
Meter display signal			T				R					
Position light request signal			T				R					R
Rear window defogger control signal			T									R
	R				R							T
Run-flat tire warning display signal			T				R					
			R						T			
Sleep wake up signal			T				R					R
Starter control relay signal			T									R
Starter relay status signal			T									R
			R									T
Steering lock relay signal			T									R
			R									T
Theft warning horn request signal			T									R
Tire pressure warning lamp signal			T		R		R					
			R		R				T			
Trunk switch signal			T				R					
Turn indicator signal			T				R					
Rear window defogger switch signal			R		T							
A/C switch signal	R					T						
Blower fan motor switch signal	R					T						
Fuel level sensor signal	R						T					
Odometer signal			R				T					
Parking brake switch signal		R	R				T					
Seat belt buckle switch signal			R				T					
Sleep-ready signal			R				T					
			R									T
Transmission oil pressure signal					R		T					
							R			T		
Transmission oil temperature signal					R		T					
		R					R			T		
Vehicle speed signal	R		R				T		R	R		R
	R	R	R	R			R		R	R	T	
Wake up signal			R				T					
Steering angle sensor signal		R		R				T			R	
Low tire pressure warning display signal							R		T			

CAN COMMUNICATION SYSTEM

< FUNCTION DIAGNOSIS >

[CAN]

Signal name/Connecting unit	ECM	4WD	BCM	E-SUS	AV	HVAC	M&A	STRG	TPMS	TCM	ABS	IPDM-E
Tire pressure monitoring system warning display signal							R		T			
Tire pressure signal					R				T			
Input shaft revolution signal	R									T		
Output shaft revolution signal	R									T		
Shift lever position check display signal							R			T		
Shift position signal		R	R*				R			T	R	
Snow mode switch signal	R									T		
Transmission clutch high temperature warning display signal							R			T		
Transmission oil high temperature warning display signal							R			T		
Transmission self-diagnosis signal	R									T		
Transmission system check display signal							R			T		
Transmission system warning display signal							R			T		
Transmission warning light signal							R			T		
ABS malfunction signal							R				T	
ABS operation signal				R						R	T	
ABS warning display signal							R				T	
Brake pressure control signal				R							T	
Brake warning lamp signal							R				T	
Decel G signal		R									T	
Side G sensor signal		R		R						R	T	
SLIP indicator lamp signal							R				T	
Stop lamp switch signal				R							T	
VDC malfunction signal							R				T	
VDC OFF indicator lamp signal							R				T	
VDC operation signal										R	T	
Yaw rate sensor signal		R									T	
Front wiper stop position signal			R									T
High beam status signal	R											T
Hood switch signal			R									T
Low beam status signal	R											T
Push-button ignition switch status signal			R									T
Steering lock unit status signal			R									T

*: P, N position signal only

NOTE:

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN COMMUNICATION SYSTEM

< COMPONENT DIAGNOSIS >


[CAN]

COMPONENT DIAGNOSIS

CAN COMMUNICATION SYSTEM

Component Parts Location

INFOID:000000003931368



JPM1A1069ZZ

- | | | |
|--|-------------------------------|----------------------------|
| 1. BCM M122 | 2. ECM M107 | 3. E-SUS control unit M110 |
| 4. IPDM E/R E6 | 5. AV control unit M81 | 6. A/C auto amp. M66 |
| 7. ABS actuator and electric unit (control unit) E41 | 8. Data link connector M24 | 9. Combination meter M53 |
| 10. Low tire pressure warning control unit M14 | 11. Steering angle sensor M37 | 12. TCM B45 |
| 13. Air bag diagnosis sensor unit M147 | 14. AWD control unit B213 | |

CAN COMMUNICATION SYSTEM


< COMPONENT DIAGNOSIS >

[CAN]

Wiring Diagram - CAN SYSTEM -

INFOID:000000003931369

CAN SYSTEM



2008/03/14


JCMWA2100GB

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN COMMUNICATION SYSTEM

< COMPONENT DIAGNOSIS >

[CAN]



JCMIA2101GB


CAN COMMUNICATION SYSTEM

< COMPONENT DIAGNOSIS >

[CAN]


CAN SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
68	P	-
70	L	-

Connector No.	B3
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
6	P	-

Connector No.	B45
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	RH40FB-R28-L-LH-Z




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	CAN-H
15	P	CAN-L

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
61	P	-
62	L	-
69	P	-
70	L	-

Connector No.	B213
Connector Name	AWD CONTROL UNIT
Connector Type	TH10FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
8	L	CAN-H
16	P	CAN-L

Connector No.	E6
Connector Name	IPM, E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH80FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-

Connector No.	E11
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	AE240FB-AJ24



Terminal No.	Color of Wire	Signal Name [Specification]
15	P	CAN-L
30	L	CAN-H

Connector No.	E104
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
6	P	-

JCM/A2102GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


CAN COMMUNICATION SYSTEM

< COMPONENT DIAGNOSIS >

[CAN]


CAN SYSTEM

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
68	P	-
70	L	-

Connector No.	M14
Connector Name	LOW TIRE PRESSURE WARNING CONTROL UNIT
Connector Type	TH32FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	P	CAN-(L)
2	L	CAN-(H)

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M37
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH48FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
2	P	CAN-L
5	L	CAN-H

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	SAB4QFW




Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

Connector No.	M66
Connector Name	A/C AUTO AMP.
Connector Type	SAB4QFW




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	CAN-H
2	P	CAN-L

Connector No.	M81
Connector Name	AV CONTROL UNIT
Connector Type	TH48FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
52	L	CAN-H
53	P	CAN-L

Connector No.	M92
Connector Name	WIRE TO WIRE
Connector Type	TH48FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
8	P	-


CAN COMMUNICATION SYSTEM

< COMPONENT DIAGNOSIS >

[CAN]


CAN SYSTEM

Connector No.	M107
Connector Name	ECM
Connector Type	RH24FY-R26-R-LH-Z




Terminal No.	Color of Wire	Signal Name [Specification]
97	P	VEHCAN-L1
101	L	VEHCAN-H1

Connector No.	M110
Connector Name	E-SUS CONTROL UNIT
Connector Type	FE21FE-FHC2




Terminal No.	Color of Wire	Signal Name [Specification]
1	P	CAN-L
3	L	CAN-H

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
61	P	-
62	L	-
69	P	-
70	L	-

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4GF-B-NH




Terminal No.	Color of Wire	Signal Name [Specification]
90	P	CAN-L
91	L	CAN-H

Connector No.	M147
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	TK28FY-EX-SC




Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
46	P	CAN-L

Connector No.	M271
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
8	P	-

Connector No.	M272
Connector Name	CAN I/F
Connector Type	TH80FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
3	L	CAH-H
7	P	CAN-L

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MALFUNCTION AREA CHART

< COMPONENT DIAGNOSIS >

[CAN]

MALFUNCTION AREA CHART

Main Line

INFOID:000000003931370

Malfunction Area	Reference
Main line between AWD control unit and BCM	LAN-33. "Diagnosis Procedure"
Main line between BCM and combination meter	LAN-34. "Diagnosis Procedure"
Main line between combination meter and steering angle sensor	LAN-35. "Diagnosis Procedure"
Main line between steering angle sensor and data link connector	LAN-36. "Diagnosis Procedure"
Main line between data link connector and TCM	LAN-37. "Diagnosis Procedure"
Main line between TCM and ABS actuator and electric unit (control unit)	LAN-38. "Diagnosis Procedure"

Branch Line

INFOID:000000003931371

Malfunction Area	Reference
ECM branch line circuit	LAN-39. "Diagnosis Procedure"
AWD control unit branch line circuit	LAN-40. "Diagnosis Procedure"
Air bag diagnosis sensor unit branch line circuit	LAN-41. "Diagnosis Procedure"
BCM branch line circuit	LAN-42. "Diagnosis Procedure"
E-SUS control unit branch line circuit	LAN-43. "Diagnosis Procedure"
AV control unit branch line circuit	LAN-44. "Diagnosis Procedure"
A/C auto amp. branch line circuit	LAN-45. "Diagnosis Procedure"
Combination meter branch line circuit	LAN-46. "Diagnosis Procedure"
Steering angle sensor branch line circuit	LAN-47. "Diagnosis Procedure"
Data link connector branch line circuit	LAN-48. "Diagnosis Procedure"
Low tire pressure warning control unit branch line circuit	LAN-49. "Diagnosis Procedure"
TCM branch line circuit	LAN-50. "Diagnosis Procedure"
ABS actuator and electric unit (control unit) branch line circuit	LAN-51. "Diagnosis Procedure"
IPDM E/R branch line circuit	LAN-52. "Diagnosis Procedure"

Short Circuit

INFOID:000000003931372

Malfunction Area	Reference
CAN communication circuit	LAN-53. "Diagnosis Procedure"

MAIN LINE BETWEEN 4WD AND BCM CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN 4WD AND BCM CIRCUIT

Diagnosis Procedure

INFOID:000000003931375

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B201
 - Harness connector M117

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B201 and M117.
2. Check the continuity between the harness connector terminals.

Connector No.	Terminal No.		Continuity
B201	70	62	Existed
	69	61	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the AWD control unit and the harness connector B201.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of BCM.
2. Check the continuity between the harness connector and the BCM harness connector.

Harness connector		BCM harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M117	70	M122	91	Existed
	69		90	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14. "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the AWD control unit and the BCM.

NO >> Repair the main line between the harness connector M117 and the BCM.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN BCM AND M&A CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN BCM AND M&A CIRCUIT

Diagnosis Procedure

INFOID:000000003931373

INSPECTION PROCEDURE

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - BCM
 - Combination meter
4. Check the continuity between the BCM harness connector and the combination meter harness connector.

BCM harness connector		Combination meter harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M122	91	M53	21	Existed
	90		22	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the BCM and the combination meter.

NO >> Repair the main line between the BCM and the combination meter.

MAIN LINE BETWEEN M&A AND STRG CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN M&A AND STRG CIRCUIT

Diagnosis Procedure

INFOID:000000003931418

INSPECTION PROCEDURE

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - Combination meter
 - Steering angle sensor
4. Check the continuity between the combination meter harness connector and the steering angle sensor harness connector.

Combination meter harness connector		Steering angle sensor harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M53	21	M37	5	Existed
	22		2	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the combination meter and the steering angle sensor.

NO >> Repair the main line between the combination meter and the steering angle sensor.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN STRG AND DLC CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN STRG AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000003931417

INSPECTION PROCEDURE

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - Steering angle sensor
4. Check the continuity between the steering angle sensor harness connector and the data link connector.

Steering angle sensor harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	5	M24	6	Existed
	2		14	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the steering angle sensor and the data link connector.

NO >> Repair the main line between the steering angle sensor and the data link connector.

MAIN LINE BETWEEN DLC AND TCM CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN DLC AND TCM CIRCUIT

Diagnosis Procedure

INFOID:000000003931419

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M7
 - Harness connector B1

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M7 and B1.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	6	M7	70	Existed
	14		69	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the data link connector and the harness connector M7.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of TCM.
2. Check the continuity between the harness connector and the TCM harness connector.

Harness connector		TCM harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	70	B45	11	Existed
	69		15	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the data link connector and the TCM.

NO >> Repair the main line between the harness connector B1 and the TCM.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN TCM AND ABS CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN TCM AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000003931376

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B3
 - Harness connector E104

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - TCM
 - Harness connectors B3 and E104
2. Check the continuity between the TCM harness connector and the harness connector.

TCM harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B45	11	B3	1	Existed
	15		6	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the TCM and the harness connector B3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the continuity between the harness connector and the ABS actuator and electric unit (control unit) harness connector.

Harness connector		ABS actuator and electric unit (control unit) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E104	1	E41	30	Existed
	6		15	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the TCM and the ABS actuator and electric unit (control unit).

NO >> Repair the main line between the harness connector E104 and the ABS actuator and electric unit (control unit).

ECM BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931379

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M117
 - Harness connector B201

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector		Resistance (Ω)
Connector No.	Terminal No.	
M107	101 97	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the ECM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-160, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-15, "BASIC INSPECTION : Special Repair Requirement \(GT-R certified NISSAN dealer\)"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

4WD BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931377

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AWD control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AWD control unit.
2. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B213	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AWD control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-20, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-42, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931433

1. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-5, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

BCM BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931380

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M122	91	90	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-39, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-78, "Exploded View"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

E-SUS BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

E-SUS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931430

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the E-SUS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of E-SUS control unit.
2. Check the resistance between the E-SUS control unit harness connector terminals.

E-SUS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M110	3	1	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the E-SUS control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the E-SUS control unit. Refer to [SCS-44, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the E-SUS control unit. Refer to [SCS-58, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the E-SUS control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

AV BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931378

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
2. Check the resistance between the AV control unit harness connector terminals.

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	52	53	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to the following.

- Base audio with navigation: [AV-68, "AV CONTROL UNIT : Diagnosis Procedure"](#)
- BOSE audio with navigation: [AV-243, "AV CONTROL UNIT : Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to the following.
- Base audio with navigation: [AV-164, "Exploded View"](#)
 - BOSE audio with navigation: [AV-330, "Exploded View"](#)

YES (Past error)>>Error was detected in the AV control unit branch line.

- NO >> Repair the power supply and the ground circuit.

HVAC BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931422

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M66	1	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-62. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-109. "Exploded View"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931382

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M53	21	22	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-54, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-128, "Exploded View"](#).
YES (Past error)>>Error was detected in the combination meter branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931383

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-95, "Wiring Diagram - BRAKE CONTROL SYSTEM - \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-121, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

DLC BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931381

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> Repair the data link connector branch line.

TPMS BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

TPMS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931385

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the low tire pressure warning control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of low tire pressure warning control unit.
2. Check the resistance between the low tire pressure warning control unit harness connector terminals.

Low tire pressure warning control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	2	1	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the low tire pressure warning control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the low tire pressure warning control unit. Refer to [WT-42, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the low tire pressure warning control unit. Refer to [WT-71, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the low tire pressure warning control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

TCM BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931429

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

TCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B45	11	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Replace the body harness.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-187, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCM. Refer to [TM-260, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the TCM branch line.
NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931386

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E41	30	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-81, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-118, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

IPDM-E BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003931387

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E6	40	39	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-18, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-32, "Exploded View"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000003931388

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M24	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M24	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND IPDM E/R TERMINATION CIRCUIT

1. Remove the ECM and the IPDM E/R.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
101	97	Approx. 108 – 132

3. Check the resistance between the IPDM E/R terminals.


IPDM E/R		Resistance (Ω)
Terminal No.		
40	39	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the IPDM E/R.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and IPDM E/R have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN 4WD AND BCM CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

COMPONENT DIAGNOSIS

MAIN LINE BETWEEN 4WD AND BCM CIRCUIT

Diagnosis Procedure

INFOID:000000003940075

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B201
 - Harness connector M117

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B201 and M117.
2. Check the continuity between the harness connector terminals.

Connector No.	Terminal No.		Continuity
B201	70	62	Existed
	69	61	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair the main line between the AWD control unit and the harness connector B201.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of BCM.
2. Check the continuity between the harness connector and the BCM harness connector.

Harness connector		BCM harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M117	70	M122	91	Existed
	69		90	Existed

Is the inspection result normal?

- YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).
 YES (Past error)>>Error was detected in the main line between the AWD control unit and the BCM.
 NO >> Repair the main line between the harness connector M117 and the BCM.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN BCM AND M&A CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

MAIN LINE BETWEEN BCM AND M&A CIRCUIT

Diagnosis Procedure

INFOID:000000003940076

INSPECTION PROCEDURE

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - BCM
 - Combination meter
4. Check the continuity between the BCM harness connector and the combination meter harness connector.

BCM harness connector		Combination meter harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M122	91	M53	21	Existed
	90		22	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the BCM and the combination meter.

NO >> Repair the main line between the BCM and the combination meter.

MAIN LINE BETWEEN M&A AND STRG CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

MAIN LINE BETWEEN M&A AND STRG CIRCUIT

Diagnosis Procedure

INFOID:000000003940078

INSPECTION PROCEDURE

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - Combination meter
 - Steering angle sensor
4. Check the continuity between the combination meter harness connector and the steering angle sensor harness connector.

Combination meter harness connector		Steering angle sensor harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M53	21	M37	5	Existed
	22		2	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the combination meter and the steering angle sensor.

NO >> Repair the main line between the combination meter and the steering angle sensor.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN STRG AND DLC CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

MAIN LINE BETWEEN STRG AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000003940079

INSPECTION PROCEDURE

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - Steering angle sensor
4. Check the continuity between the steering angle sensor harness connector and the data link connector.

Steering angle sensor harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	5	M24	6	Existed
	2		14	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the steering angle sensor and the data link connector.

NO >> Repair the main line between the steering angle sensor and the data link connector.

MAIN LINE BETWEEN DLC AND TCM CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

MAIN LINE BETWEEN DLC AND TCM CIRCUIT

Diagnosis Procedure

INFOID:000000003940080

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M7
 - Harness connector B1

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M7 and B1.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	6	M7	70	Existed
	14		69	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the data link connector and the harness connector M7.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of TCM.
2. Check the continuity between the harness connector and the TCM harness connector.

Harness connector		TCM harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	70	B45	11	Existed
	69		15	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the data link connector and the TCM.

NO >> Repair the main line between the harness connector B1 and the TCM.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN TCM AND ABS CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

MAIN LINE BETWEEN TCM AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000003940081

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B3
 - Harness connector E104

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - TCM
 - Harness connectors B3 and E104
2. Check the continuity between the TCM harness connector and the harness connector.

TCM harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B45	11	B3	1	Existed
	15		6	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the TCM and the harness connector B3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the continuity between the harness connector and the ABS actuator and electric unit (control unit) harness connector.

Harness connector		ABS actuator and electric unit (control unit) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E104	1	E41	30	Existed
	6		15	Existed

Is the inspection result normal?

YES (Present error)>>Connect all the connectors and diagnose again. Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).

YES (Past error)>>Error was detected in the main line between the TCM and the ABS actuator and electric unit (control unit).

NO >> Repair the main line between the harness connector E104 and the ABS actuator and electric unit (control unit).

ECM BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940082

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M117
 - Harness connector B201

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector		Resistance (Ω)
Connector No.	Terminal No.	
M107	101 97	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-160, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-15, "BASIC INSPECTION : Special Repair Requirement \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

4WD BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940083

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AWD control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AWD control unit.
2. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B213	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AWD control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-20, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-42, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940084

1. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-5, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

BCM BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940085

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M122	91	90	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-39, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-78, "Exploded View"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

E-SUS BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

E-SUS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940086

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the E-SUS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of E-SUS control unit.
2. Check the resistance between the E-SUS control unit harness connector terminals.

E-SUS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M110	3	1	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the E-SUS control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the E-SUS control unit. Refer to [SCS-44, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the E-SUS control unit. Refer to [SCS-58, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the E-SUS control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

AV BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940087

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
2. Check the resistance between the AV control unit harness connector terminals.

AV control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	52	53	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to the following.

- Base audio with navigation: [AV-68, "AV CONTROL UNIT : Diagnosis Procedure"](#)
- BOSE audio with navigation: [AV-243, "AV CONTROL UNIT : Diagnosis Procedure"](#)

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to the following.
- Base audio with navigation: [AV-164, "Exploded View"](#)
 - BOSE audio with navigation: [AV-330, "Exploded View"](#)

YES (Past error)>>Error was detected in the AV control unit branch line.

- NO >> Repair the power supply and the ground circuit.

HVAC BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940088

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M66	1	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-62. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-109. "Exploded View"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940089

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M53	21	22	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-54, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-128, "Exploded View"](#).
YES (Past error)>>Error was detected in the combination meter branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940090

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-95, "Wiring Diagram - BRAKE CONTROL SYSTEM - \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-121, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

DLC BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940091

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	6	14	Approx. 54 – 66

Is the measurement value within the specification?

- YES (Present error)>>Diagnose again. Refer to [LAN-14. "Trouble Diagnosis Flow Chart"](#).
YES (Past error)>>Error was detected in the data link connector branch line circuit.
NO >> Repair the data link connector branch line.

TPMS BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

TPMS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940093

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the low tire pressure warning control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of low tire pressure warning control unit.
2. Check the resistance between the low tire pressure warning control unit harness connector terminals.

Low tire pressure warning control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	2	1	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the low tire pressure warning control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the low tire pressure warning control unit. Refer to [WT-42, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the low tire pressure warning control unit. Refer to [WT-71, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the low tire pressure warning control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

TCM BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940094

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

TCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B45	11	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Replace the body harness.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-187, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCM. Refer to [TM-260, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the TCM branch line.
NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940095

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E41	30	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-81, "Diagnosis Procedure \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-118, "Exploded View \(GT-R certified NISSAN dealer\)"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

IPDM-E BRANCH LINE CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000003940096

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E6	40	39	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-18, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-32, "Exploded View"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000003940097

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M24	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M24	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND IPDM E/R TERMINATION CIRCUIT

1. Remove the ECM and the IPDM E/R.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
101	97	Approx. 108 – 132

3. Check the resistance between the IPDM E/R terminals.


IPDM E/R		Resistance (Ω)
Terminal No.		
40	39	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the IPDM E/R.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT

< COMPONENT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and IPDM E/R have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.